

M A G I X

DIP SWICH.

		1	2	3	4	5	6	7	8
TEST MODE	YES NO	ON OFF							
DIFFIC- ULTY SET	NORMAL HARD HARDEST EASY		OFF ON OFF ON	OFF OFF ON ON					
SCREEN MODE	NORMAL REVERSE				OFF ON				
DEMO SOUND						ON OFF			
COIN/ CREDIT	1Coin1Credit 1Coin2Credit 1Coin3Credit 1Coin4Credit 2Coin1Credit 2Coin3Credit 3Coin1Credit 4coin1Credit						OFF ON OFF ON OFF ON OFF ON	OFF OFF ON ON OFF OFF ON ON	OFF OFF OFF OFF ON ON ON ON